

## DSS Player Pro Release 4 Update Version 4.10.1

### Description:

This update (P4UP101EN.EXE) applies to **Release 4.x only** of the DSS Player Pro Dictation and Transcription Modules (Windows 2000/XP/Vista only). To check the current version of your DSS Player Pro software, start your DSS Player Pro application then click on the Help menu → About...

If your application version is not 4.10.1, it is recommended you download and install this software update.

**Note:** This update will not upgrade DSS Player Pro pre-release 4. For customers who would like to upgrade their DSS Player Pro release 3 software to Release 4 software, please contact your Olympus Authorized Audio Dealer.

### Software bugs fixes and/or enhancements:

Software Module	OS	Change	Description
Both	All	New	DSS Player Pro R4.10 (v4.10.0) supports Citrix Presentation Environment when installed using R4.10 CD bundled with DS-4000/AS-4000 or R4.10 MSI image.  Please note, installing R4.10 software update module, will not enable Citrix support in the DSS Player Pro. Please contact your Olympus Authorized Dealer for details.
Both	All	New	Full support for MP3 file format in the DM and TM.
Both	All	Bug	If you disable the system service "Terminal Services", Directrec and/or RS-27 HID footswitch stops working.
DM	All	Bug	If you install the DM with ALL User Settings and try to use the encryption, the DM will erratically enable and disable encryption on previously set folders.
Both	All	Bug	If the dictation files are shared over a network and reside on a Novell server, the DSS Player cannot play the file.
DM	All	Bug	If dictations are shared between authors and transcriptionists over the network, the TM cannot move dictation from one folder to another if the files is highlighted in the DM. Also, Finished files will not be moved to the Finished folder in this case as well. File will change status to Finished but stay in the same folder.
DM	All	Bug	"Drag and drop" a file from one of the backup folders to another folder is disabled.
Both	All	Bug	When you download dictations from DVR with "Edit Job Data" prompt enabled, the Preview function does not work in some situations.



3500 CORPORATE Parkway  
Center Valley, PA 18034  
DIGITAL TECHNICAL SUPPORT  
CONSUMER PRODUCTS GROUP  
(888) 553-4448  
<http://support.olympusamerica.com>

### **Installation Instructions:**

NOTE: It is recommended that you logon to the PC as an administrator when installing this software update.

1. Click the **DSS Player Pro Release 4.x Update Version 4.10.1** link to start the download.
2. Save the file to your hard disk.
3. Close all open programs.
4. Double-click the P4UP101EN.EXE program file on your hard disk to start the update program.
5. Follow the instructions on the screen to complete the installation.