



## DSS Player for Mac Software Update v. 7.23

### Description

This software update module (**DSSPlayerV723Update.dmg**) applies to DSS Player for Mac V7 versions 7.0. through 7.22.

### System Requirements

The minimum system requirements to operate DSS Player for Mac V7 are shown below:

| Item               | Condition  |
|--------------------|--|
| OS                 | Mac OS X 10.3.9 or later   |
| CPU                | Power PC G3 500MHz or better<br>Intel Core Solo / Duo 1.5GHz or better |
| Memory             | 256 MB or more   |
| Disk space of HDD  | 200 MB or more   |
| Drive              | CD drive   |
| Display            | 1024 x 768 dots or more<br>32,000 colors or more                       |
| USB port*1         | One or more available  |
| Audio input/output | Earphone, or speaker output  |
| Others             | Safari 1.0 or later, QuickTime 7 or later<br>Flip4Mac (WMA playback)*2 |

\*1 Operation will not be guaranteed when an expansion USB port is used.

\*2 When Windows Media® Components for QuickTime, Flip4Mac™, is installed you can directly play the WMA file with the DSS Player. You can use WMA file playback function free of charge. For further information, please refer to the Flip4Mac web site.

### Software Enhancements

| OS            | Type | Description  |
|---------------|------|--|
| Mac OS X 10.6 | Bug  | Device driver updated.<br><br>Sometimes Olympus Digital Recorders have not been recognized by some computers running Mac OS X 10.6 because the device driver was not updated correctly. This version fixes the problem. After updating to DSS Player V7.23, reboot the computer. When it restarts, the computer will recognize the recorder. |

©2009 OLYMPUS IMAGING AMERICA INC. All rights reserved. No part of this publication may be reproduced, in whole or in part, without the express written permission of Olympus Imaging America Inc.

OLYMPUS is a registered trademark of Olympus Corporation. All other trademarks and registered trademarks herein are the property of their respective holders.



DIGITAL TECHNICAL SUPPORT  
OLYMPUS IMAGING AMERICA INC.  
888-553-4448

<http://support.olympusamerica.com>

Last updated: November 23, 2009

### **Installation Instructions**

1. Click the **DSS Player for Mac Update 7.23** link to start the download.
2. Save the file (**DSSPlayerV723Update.dmg**) to the Macintosh computer's hard disk.
3. Close all open programs on the computer.
4. Navigate to the downloaded file, **DSSPlayerV723Update.dmg**, and then double-click on it to open the disk image.
5. Double-click the **DSS Player (MAC) Updater X**.
6. Follow the instructions on the screen to complete the installation.

©2009 OLYMPUS IMAGING AMERICA INC. All rights reserved. No part of this publication may be reproduced, in whole or in part, without the express written permission of Olympus Imaging America Inc.

OLYMPUS is a registered trademark of Olympus Corporation. All other trademarks and registered trademarks herein are the property of their respective holders.